

Misc. Renewal Parts

SECTION CONTENTS

- ◆ Switches 185 & 186
- ◆ Heaters 187
- ◆ Thermostats 188
- ◆ Gauges 188
- ◆ Coils 189
- ◆ Valves 190
- ◆ Gas Transfer & Filter 191
- ◆ Bearings 191
- ◆ Resistors 192 & 193
- ◆ Micro Switch 194
- ◆ Pilot Valve Piston 194
- ◆ Run Time Meter 194
- ◆ Springs 195
- ◆ Shims 195
- ◆ Counter 196
- ◆ Misc. Parts 196
- ◆ Bushings 197
- ◆ Porcelains 198

Switches

HVB PART NUMBER	DESCRIPTION
18-0000-00	SF6 PRESSURE SWITCH (5PS/68P1)
18-0000-01	SF6 PRESSURE SWITCH (5PS/68P2)
18-0000-02	SF6 PRESSURE SWITCH (5PS/68P6)
18-0000-03	SF6 PRESSURE SWITCH (5PS/68P5)
18-0001-00	SF6 PRESSURE SWITCH (6PS/26P1)
18-0001-01	SF6 PRESSURE SWITCH
18-0002-00	SF6 PRESSURE SWITCH (6PS/45P1)
18-0002-01	SF6 PRESSURE SWITCH (6PS/45P2)
18-0002-02	SF6 PRESSURE SWITCH (6PS/45P3)
18-0002-03	SF6 PRESSURE SWITCH
18-0003-00	SF6 PRESSURE SWITCH (6PS/46P1)
18-0004-00	SF6 PRESSURE SWITCH (5PS/54)
18-0018-00	SF6 PRESSURE SWITCH (6TC/2P1)




SF₆ Pressure Switches



Air Pressure Switches

HVB PART NUMBER	DESCRIPTION
18-0100-00	AIR PRESSURE SWITCH (5PS/35P1)
18-0100-01	AIR PRESSURE SWITCH (5PS/35P2)
18-0100-02	AIR PRESSURE SWITCH (5PS/35P4)
18-0100-03	AIR PRESSURE SWITCH (5PS/35P10)
18-0100-04	AIR PRESSURE SWITCH (5PS/35P12)
18-0100-05	AIR PRESSURE SWITCH (5PS/35P17)
18-0100-06	AIR PRESSURE SWITCH (5PS/35P18)
18-0100-07	AIR PRESSURE SWITCH (5PS/35P19)
18-0100-08	AIR PRESSURE SWITCH (5PS/35P3)
18-0101-00	AIR PRESSURE SWITCH (6PS/47P1)
18-0101-01	AIR PRESSURE SWITCH (6PS/47P2)
18-0101-02	AIR PRESSURE SWITCH (6PS/47P3)
18-0101-03	AIR PRESSURE SWITCH (6PS/47P4)
18-0101-04	AIR PRESSURE SWITCH (6PS/47P5)
18-0101-05	AIR PRESSURE SWITCH (6PS/47P6)
18-0101-06	AIR PRESSURE SWITCH (6PS/47P7)
18-0101-07	AIR PRESSURE SWITCH (6PS/47P8)
18-0109-00	AIR PRESSURE SWITCH




Governor Switch (18-0103-00)
(Same as 18-0102-00)

HVB PART NUMBER	DESCRIPTION
18-0102-00	GOVERNOR SWITCH (2PS/P1)
18-0103-00	GOVERNOR SWITCH (2PS/P2)
18-0105-00	GOVERNOR SWITCH (2PSW/P3)




Governor Swith (18-0105-00)


Heaters




21-0300-00



21-0300-01




21-0302-00




21-0301-00 & 01

HVB PART NUMBER	DESCRIPTION
21-0300-00	HEATER,160W 250V
21-0300-01	HEATER,350W 250V
21-0300-02	HEATER,160W 125V
21-0300-03	HEATER,160W 100VAC
21-0301-00	HEATER,1250W 240V
21-0301-01	HEATER,1250W 208VAC
21-0302-00	HEATER,340W

Thermostat



(21-0604-00)



(21-0603-00)

HVB PART NUMBER	DESCRIPTION
21-0600-00	THERMOSTAT,CHROMALOX
21-0601-00	THERMOSTAT,CHROMALOX
21-0602-00	THERMOSTAT,ON=52F OFF=67F
21-0603-00	THERMOSTAT,60T(80-90)
21-0604-00	THERMOSTAT,ON=95F OFF=110
21-0605-00	THERMOSTAT ON=-10 OFF=5
21-0607-00	THERMOSTAT,CLOSE AT -28C

Gauges




HVB PART NUMBER	DESCRIPTION
14-2000-00	GAUGE; PRESSURE (0-160psi-NEW STYLE)
14-2000-01	GAUGE; PRESSURE (0-400psi-NEW STYLE)

Coils




TRIP COIL




CLOSE COIL

HVB PART NUMBER	DESCRIPTION
21-0800-00	COIL,TRIP 125VDC 5OHM
21-0801-00	COIL,TRIP 125VDC 20OHM
21-0802-00	COIL,TRIP 48VDC 4.6OHM
21-0803-00	COIL,TRIP 250VDC 11OHM
21-0804-00	COIL,TRIP 250VDC
21-0805-00	COIL,TRIP 1.3OHM
21-0806-00	COIL,TRIP 2 OHM
21-0807-00	COIL,TRIP 242/50 3000A
21-0808-00	COIL,TRIP &CLOSE 125VDC
21-0900-00	COIL,CLOSE 125VDC 16OHM
21-0901-00	COIL,CLOSE 125VDC 62.5OHM
21-0902-00	COIL,CLOSE 100VDC 62.5OHM
21-0903-00	COIL,CLOSE 48VDC 14.5OHM
21-0904-00	COIL,CLOSE 250VDC 64OHM
21-0905-00	COIL,CLOSE 250VDC 250OHM
21-0906-00	COIL,CLOSE 3OHM
21-0907-00	COIL,CLOSE 242/50 3000A


Valves



CHECK VALVE




RELIEF VALVE



SAFETY VALVE

HVB PART NUMBER	DESCRIPTION
14-0000-01	VALVE; RELIEF (100 psi)
14-0002-00	VALVE; SAFETY 5HP COMP.
14-0006-00	VALVE; SAFETY 1.5 HP COMP.
14-0007-00	VALVE; CHECK (1.5HP & 3.0HP)
14-0008-00	VALVE; CHECK (1.5HP & 3.0HP)
14-0009-00	VALVE; SAFETY RELIEF (284 psi)
14-0022-00	VALVE; SAFETY RELIEF (300 psi) ASME
14-0022-02	VALVE; SAFETY RELIEF (284 psi) ASME
14-0027-01	VALVE; SAFETY (300 psi)

Gas Transfer & Filter



TRANSFER TOOL




FILTER

HVB PART NUMBER	DESCRIPTION
12-1000-00	FILTER; SF6 GAS
50-0004-02	GAS TRANSFER TOOL; NEW STYLE

Bearings

25-5000-00



25-5001-00



HVB PART NUMBER	DESCRIPTION
25-5000-00	BEARING; ROLLER (ARMATURE ASSEMBLY)
25-5001-00	BEARING; ROLLER (HOOK ASSEMBLY)

Resistors




HVB PART NUMBER	DESCRIPTION
21-0003-00	RESISTOR (24 ohm)
21-0006-00	RESISTOR (22 ohm)
21-0007-00	RESISTOR (50 ohm)
21-0007-01	RESISTOR (60 ohm)

HVB PART NUMBER	DESCRIPTION
21-0002-00	RESISTOR (500 ohm)
21-0000-13	RESISTOR (200 ohm)
21-0001-00	RESISTOR (2500 ohm/8 W)
21-0001-01	RESISTOR (200 ohm/8 W)
21-0001-02	RESISTOR (5 ohm/ 25 W)
21-0004-00	RESISTOR (11 ohm)
21-0005-00	RESISTOR (18 ohm)
21-0008-00	RESISTOR (8.1 ohm)




HVB PART NUMBER	DESCRIPTION
21-0003-00	RESISTOR (15-5) ohm
21-0007-00	RESISTOR (22-7) ohm
21-0006-00	RESISTOR (60-20) ohm
21-0000-08	RESISTOR (2-8.1) ohm
21-0000-09	RESISTOR (88-38) ohm
21-0000-11	RESISTOR (15-7) ohm




HVB PART NUMBER	DESCRIPTION
21-0000-01	RESISTOR (22-7-7) ohm
21-0000-04	RESISTOR (15-5-5) ohm
21-0000-07	RESISTOR (60-20-20) ohm
21-0000-10	RESISTOR (88-38-38) ohm

HVB PART NUMBER	DESCRIPTION
21-0000-00	RESISTOR (22-24-24) ohm
21-0000-12	RESISTOR (50-50-60) ohm




Micro Switch



HVB PART NUMBER	DESCRIPTION
18-0602-00	MICRO SWITCH

Pilot Valve Piston

HVB PART NUMBER	DESCRIPTION
23-5008-00	PILOT VALVE PISTON 362/50
23-5009-00	PILOT VALVE PISTON 362/40




Run Time Meter




HVB PART NUMBER	DESCRIPTION
12-0001-01	RUN TIME METER

Springs






HVB PART NUMBER	DESCRIPTION
25-1004-00	SPRING; CLOSE COIL ARMATURE
25-1003-00	SPRING; CLOSE LEVER RETURN
23-4004-00	SPRING; LATCH RETURN

Shims



HVB PART NUMBER	DESCRIPTION
01-2039-00	SHIM; CLOSING STOP PLATE
01-2040-00	SHIM; CLOSING STOP PLATE

Counter




HVB PART NUMBER	DESCRIPTION
21-1501-00	OPERATIONS COUNTER
24-2064-00	OPERATIONS COUNTER
21-1502-00	OPERATIONS COUNTER

Misc. Parts

HVB PART NUMBER	DESCRIPTION
05-0095-00	CLEANER; ALCOHOL (1 QT)
05-0011-00	GREASE; HITALUB 280 (8 oz)
05-0122-00	GREASE; MOBIL #28 (8 oz)
05-0084-00	OIL; COMPRESSOR, ANDEROL 500(QT)

Bushing Assembly




HVB PART NUMBER	DESCRIPTION
41-2006-00	BUSHING ASSEMBLY, 72.5kV
50-1000-00	BUSHING ASSEMBLY, 121kV
50-1000-01	BUSHING ASSEMBLY, 121kV, EXTRA CREEP
50-1000-02	BUSHING ASSEMBLY, 121kV, BROWN
50-2000-00	BUSHING ASSEMBLY, 145kV
50-2000-01	BUSHING ASSEMBLY, 145kV, EXTRA CREEP
50-2000-02	BUSHING ASSEMBLY, 145kV, 3000A
50-2000-03	BUSHING ASSEMBLY, 145kV, 2000A, 142" CREEP
50-2000-04	BUSHING ASSEMBLY, 145kV, 3000A, 142" CREEP
50-3000-00	BUSHING ASSEMBLY, 169kV
50-4000-00	BUSHING ASSEMBLY, 242kV
50-4000-01	BUSHING ASSEMBLY, 242kV, 71" STRIKE
50-4000-04	BUSHING ASSEMBLY, 242kV, EXTRA CREEP
50-4000-05	BUSHING ASSEMBLY, 242Kv, 3000AMP
50-4000-10	BUSHING ASSEMBLY, 242kV/50-63kA
50-4000-11	BUSHING ASSEMBLY, 242kV/50-63kA EXTRA CREEP
50-4000-12	BUSHING ASSEMBLY, 242kV/50-63kA, 3000A
50-4000-13	BUSHING ASSEMBLY, 242kV/50-63kA, 3000A, EXTRA CREEP
50-4020-00	BUSHING ASSEMBLY, 242kV, NEW STYLE
50-4020-01	BUSHING ASSEMBLY, 242kV, 3000A, NEW STYLE
50-4020-02	BUSHING ASSEMBLY, 242kV/50-63kA, NEW STYLE
50-4020-03	BUSHING ASSEMBLY, 242kV/50-63kA, 3000A NEW STYLE
50-5000-00	BUSHING ASSEMBLY, 362kV
50-5000-01	BUSHING ASSEMBLY, 362kV, BROWN
50-5000-02	BUSHING ASSEMBLY, 362kV, 311" CREEP
50-6000-00	BUSHING ASSEMBLY, 550kV

Includes:

- Porcelain
- Center Conductor
- Top Cap
- All Gaskets
- Hardware

Porcelain



HVB PART NUMBER	DESCRIPTION
02-1000-00	PORCELAIN,121kV, GRAY
02-1000-01	PORCELAIN,121kV, BROWN
02-1000-02	PORCELAIN,121kV, GRAY, EXTRA CREEP
02-2000-00	PORCELAIN,145kV, GRAY
02-2000-01	PORCELAIN,145kV, BROWN
02-2000-03	PORCELAIN,145kV, GRAY, 115" CREEP
02-2000-04	PORCELAIN,145kV, GRAY, 142" CREEP
02-3000-00	PORCELAIN,169kV, GRAY
02-4000-00	PORCELAIN,242kV, GRAY
02-4000-01	PORCELAIN,242kV, BROWN
02-4000-02	PORCELAIN,242kV, GRAY, EXTRA CREEP
02-4015-00	PORCELAIN,242kV, GRAY, NEW DESIGN
02-5000-00	PORCELAIN,362kV, GRAY
02-5000-01	PORCELAIN,362kV, GRAY, 311" CREEP
02-5000-02	PORCELAIN,362kV, BROWN
02-5000-03	PORCELAIN,362kV, BROWN, 311" CREEP
03-2000-00	PORCELAIN,72.5kV, 2000A GRAY